


1	125F0002	Culasse
2	125F0089	vis
3	125F0078	joint
4	125F0088	ecrou
5	125F0005	lamelle
6	125F0004	support de lamelle
7	125F0077	joint
8	125F0019	cylindre
9	125F0041	bague
10	125F0030	segment
11	125F0070	bielle
12	125F0067	roulement
13	125F0064	vilbrequin
14	125F0060	carter
15	125F0066	capot
16	125F0090	vis
17	125F0039	joint
18	125F0104	ecrou
19	125F0056	moteur
20	125F0007	embout
21	125F0044	tuyau
22	125F0013	tuyau
23	125F0134	clapet antiretour
24	125F0142	pressostat
25	125F0100	bouchon
26	125F0130	valve de sécurité
27	125F0138	manomètre
28	125F0048	tuyau
29	125F0135	régulateur de pression
30	125F0162	raccord femelle
31	125F0123	cuve 4 L
32	125F0157	protection poignée
33	125F0129	robinet de purge
34	125F0154	pied
35	125F0163	fil électrique
36	125F0008	vis
37	125F0158	bouchon
38	125F0108	rondelle
39	125F0117	rondelle
40	125F0091	vis
41	125F0043	tuyau
42	125F0107	rondelle
43	125F0169	clip
44	125F0106	ecrou



ALAIR 4/25 Oiless

AL57150