




R 32/18 P1

12R32P1

101	12B01589	ecrou	408	12B01565	arrêt
102	12B01569	défecteur	409	12B01566	ressort
103	12B01554	joint plat	410	12B01555	guide
104	12B01551	cylindre	411	12B01547	guide
105	12B01560	amortisseur	412	12B01600	goupille
106	12B01605	ecrou	413	12B00486	avance agrafes
107	12B01558	piston	414	12B01585	porte griffes
108	12B01608	joint	415	12B01604	goupille
109	12B01597	rondelle	416	12B01602	goupille
110	12B01582	couteau	417	12B01583	lien
111	12B01578	axe	418	12B01574	socle
112	12B01550	bague	419	12B01586	porte griffes
113	12B01606	joint	420	12B00263	boulon
114	12B01552	base	421	12B01603	goupille
115	12B01593	ecrou	422	12B01541	bille
116	12B01577	arrêt	423	12B01571	lien
117	12B01564	ressort	424	12B01562	guide
118	12B01596	rondelle	425	12B01592	vis
119	12B01609	joint	426	12B01576	couteau
120	12B01607	joint	427	12B01590	boulon
201	12B01542	gâchette	428	12B01595	rondelle
202	12B01601	goupille	429	12B01588	guide avance griffes
203	12B01612	joint	430	12B01587	chapeau
204	12B01614	joint	431	12B01556	poussoir
205	12B01543	valve servo commande	432	12B01561	ressort
301	12B01573	poignée	433	12B01584	guide
302	12B01436	boulon	434	12B01553	magasin
303	12B01549	crochet	435	12B01435	boulon
304	12B01610	joint	436	12B01581	arrêt
305	12B01572	tube	437	12B01591	boulon
306	12B01557	chapeau	438	12B01599	goupille
307	12B01474	protection	439	12B01613	boulon
308	12B01482	raccord	440	12B01579	guide
309	12B01544	poignée	441	12B01580	guide
401	12B01545	magasin	442	12B01594	boulon
402	12B01546	guide	443	12B01570	plaque
403	12B01611	vis	444	12B01559	ressort
404	12B01548	ressort	445	12B00056	joint
405	12B01598	rondelle	446	12B01568	magasin
406	12B01575	socle	447	12B01563	protection
407	12B01567	axe			
R 32/18 P1			12R32P1		