


Pos	Bezeichnung	alle A	PN 6040 A	PN 5040 A	PN 540 A	PN 750 A	PN 7050 A MM	PN 730 A/N	SKN 64 A 16	SKN 64A20	TN 64 A 22	TN 15 A 22	PN 3030 A	PN 2550 A	PN 2575 A HWL	RN 35 A/H
1	Ventil kpl / valve cpl	036678														
2	Ventiloberteil / upper valve p.	036681														
3	Kolben kpl / piston cpl.		035798	035797	035795	012005	012005	036481	036107	035842	035835	033617	037544	034377	012211	039378
4	Zylinder / cylinder		012004	012004	012004	012004	012004	012004	012004	012004	012004	012004	012004	034342	012210	012004
5	Puffer / pumber		012003	012003	012003	012003	012003	012003	012003	012003	012003	012003	012137	012137	012137	012003
6	Ventilbuchse / valve bushing	012008														
8	Anschlussnippel/connecting nipple	037533														
9	Auslösestift kpl / valva piston	012007														
10	Auslöser kpl. / trigger	012001														
11	Mag. Oberteil kpl. / magazine cpl.		012076	012076	012010	012010	033198	012010	012076	012076	012076		036707			
12	Bodenplatte / bottom plate		035794	036103	036251	012015	012015	036462	035937	035937	035834	035834	036710	036668	012213	039384
16	Flachdichtung / seal	036677														
17	Treiber / driver		035807	035806	035804	012025	012025	036095	036108	035836	035838	033740		033342	012219	
18	Unt. Ventilb. / lower valve b.	012021														
19	Auslöseblech / releasing blade	012023														
20	Auslöser / trigger	012022														
22	Kloben / pusher		035802	035801	035799	012012	012012	036474	037794	012078	012078	033162	034223	012602	034350	037581
23	Zugfeder / pusher spring		012038	012038	012038	012038	033187	012038	012038	012038	012038	012038	035162			
24	Druckfeder / compression spring		033939	033939	033939	033939	033939	033939	033939	033939	033939	033939				034662
25	Rasthebelr / magazine catch		012112	012112	012040	012040	012040	012040	012112	012112	012112	012112	033798			
26	Entlüftungsk. / exhaust deflec	036268														
27	Druckfeder / compression spring	036308														
28	Stütze / support		012033	012033	012033	012033	039003	012033	012033	012033	012033	012033	036708			035967
29	Druckfeder / compressing spring	012029														
30	Buchse / sleeve		012044	012044	012044	012044	012044	012044	012044	012044	012044	012044				012044
31	Auslösesicherung / safety yoke		039389	039389	012013	012013	012013	036460	039389	039389	012013	012013	036709	012138	012217	039385
32	Stößelführung / driver guide		035803	036104	036252	012024	012024	012024	012081	012081	035837	035837				
33	Vorderplatte / front plate		035831	035831	012043	012043	012043	036357	037795	036105	012085	012085	034570	012134	012214	
34	Führungsplatte / guiding plate		035933	035828	035934	012042	012042	036452	039388	035939	035841	033163	034551			
35	Seitenpl. rechts / sideplate right		012089	012089	012071	012071	039790	012071	012089	012089	012089	012089				
36	Distanzscheibe / distance plate		035808	035808	012037	012037		012037								
37	Klammernträger / staple rail		035827	035827	035935	035833	033197	036468								
38	Seitenpl. links / sideplate left		012072	012072	012072	012072	039791	012072	012072	012072	012072	012072				
39	Z-Schraube / screw		012045	012045	012045	012045	012045	012045	012045	012045	012045	012045				012045
40	Z-Schraube / screw				012145	012145	012145	012145						012145	012145	
41	Nageltr. rechts / nail trail right								037797	035940	035839	035839				
42	Nageltr. links / nail trail left								037798	035942	035840	035840				
43	Spannhülse / clamping		035923	035923												
44	INA Lagernadel / pin		035924	035924							035923	035923				
45	Zylinderstift / cylinder pin		012063	012063	012063	012063	012063	012063	012063	012063	012063	012063				
46	Spannhülse / clamping															
47	Stift / pin	034771														
48	O-Ring	012059														
49	O-Ring	034805														
50	O-Ring	034840														
51	Kolbendichtung / piston sealing	012051														
53	O-Ring	012050														
54	O-Ring	012055														
55	O-Ring	059255														
56	O-Ring	012054														
57	Sechskantmutter / nut		012068	012068	012068	012068	012068	012068	012068	012068	012068	012068				012068
58	Sechskantmutter /				012146	012146	012146	012146	012146	012146				012146		
59	Sicherungsmutter / security nut	012065														
60	Sicherungssch. / sec.washer	034908														
61	Senkschraube / screw	037141														
62	Z-Schraube / screw	035068														
63	Z-Schraube / screw		012062	012062	012062	012062	012062	012062	012062	012062	012062	012062		012062	012062	
64	Z-Schraube / screw		012066	012066	012066	012066	012066	012066	012066	012066	012066	012066				012066
65	Z-Schraube / screw		012064	012064	012064	012064	012064	012064	012064	012064	012064	012064				
66	Scheibe / washer		012067	012067	012067	012067	012067	012067	012067	012067	012067	012076				012067
67	O-Ring	034792														
68	Z-Schraube / screw		034976	034976	012066	012066	012066	012066								
69	O-Ring	034832														
70	Z-Schraube / screw		039257	039257	039257	039257	039257	039257	039257	039257	039257	039257	039257	039257	039155	039257
71	Ventilunterteil / lower valve p.	036680														
72	Ventilring kpl. / valve ring cpl.	033305														
73	Magazin / magazine													012604	012604	039204
74	Abdeckblech / cover													036754	012212	035957
75	Federrolle / springroll														012603	037489
77	Rollfeder / roll spring															037490
78	Klobengriff / pusher handle													012603		037488
79	Rollenbolzen / roll bolt															039386
80	Distanzstück / distance piece															035968
81	Z-Schraube / screw															034957
82	Schnorr-Sicherung / safety															034905
83	Z-Schraube / screw								035035	035035	035035	035035		035035	012064	
84	Spannhülse / clamping sleeve															035969
85	Spannhülse / clamping sleeve															034750
87	Rohr / tube															
88	Spannstift / pin												012139	012139	012139	
89	Z-Schraube / screw												012144	012144	012144	
90	Sicherungsscheibe / safety disc												034909	034909	034909	034909
91	Z-Schraube / screw							035005					035005			
92	Senkschraube / screw												035062			
93	Senkschraube / screw												035060			035060
95	Feder für Rasthebel / spring												035157			
96	Sicherung / clip												034932			
97	Bolzen / bolt												034774			
98	Spannhülse / clamping sleeve												034772			
99	Spannhülse / clamping sleeve												034771			
100	Magazinsch. kpl. / magazine pusher												035167			
101	Z-Schraube / screw															
102	Sicherungsscheibe / safety disc							034905					034997			
103	Anschlagbügel / magazine stop												034905			
104	Puffer für Anschlag / bumper												035156			
105	Dichtscheibe / disc												035168			
106	Z-Schraube / screw												036102	012136	012136	
107	Lasche / strap													012143	012143	
109	Klemmplatte / damping sleeve													012120	012120	
110	Anschlag / stop													012607	012607	
111	Einzelauslösung kpl. / single fire		033112	033112	033112	033112	033112	033112	033112	033112	033112	033112		012608		
112	Auslöser kpl. / trigger fire cpl.		033113	033113	033113	033113	033113	033113	033113	033113	033113	033113	033113	033113	033113	033113
113	Anschlagblech / stop		033120	033120	033120	033120	033120	033120	033120	033120	033120	033120	033120	033120	033120	033120
114	buchse / sleeve		033114	033114	033114	033114	033114	033114	033114	033114	033114	033114	033114			
115	Zugfeder / spring		033115	033115	033115	033115	033115	033115	033115	033115	033115	033115				
116	Auslösesicherung / safety yoke									</						

Alle Modelle
All Models
Todos los modelos
Tout les models
alla modellen
alla modeller
Kaikki mallit


Technische Änderungen vorbehalten / Under reserve of modifications

„Sollte das Etikett mit den Warnhinweisen unleserlich sein, so ist dieses umgehend zu entfernen und durch ein neues Klebeschild (Art.-Nr. 036771) zu ersetzen.“
Geräte ohne diesen Warnhinweis dürfen nicht betrieben werden.“

„In case the warning label is illegible please remove it immediately and replace it by the adhesive label (article no. 036771).“
It is not allowed to use tools without fixed labels.“





PN 730 A/N




MOD. **A**

PN 6040 A
PN 540 A
PN 750 A
PN 5040 A
PN 7050 A/MM
SKN 64 A/16
SKN 64 A/20
TN 64 A/22
TN 15 A/22



RN 35 A/H



PN 2550 A

PN 2575 A/HWL

This exploded view diagram illustrates the assembly of a mechanical component, likely a door handle or latch. The diagram shows the following parts and their assembly sequence:

- Top Assembly:** Part 3 (a small circular cap) is shown above part 50 (a larger circular cap). Part 50 is shown being inserted into part 5 (a cylindrical component). Part 105 (a circular base) is shown below part 5.
- Bracket Assembly:** Part 31 (a long, thin bracket) is shown being inserted into part 87 (a small rectangular component). Part 88 (a small pin) is shown being inserted into part 12 (a circular component). Part 60 (a screw) is shown being inserted into part 70 (a rectangular component).
- Main Body Assembly:** Part 28 (a bracket) is shown being inserted into part 89 (a screw). Part 59 (a screw) is shown being inserted into part 28. Part 25 (a handle) is shown being inserted into part 95 (a bracket). Part 96 (a screw) is shown being inserted into part 97 (a bracket). Part 98 (a screw) is shown being inserted into part 97.
- Bottom Assembly:** Part 89 (a screw) is shown being inserted into part 90 (a bracket). Part 91 (a screw) is shown being inserted into part 90. Part 34 (a bracket) is shown being inserted into part 33 (a bracket). Part 92 (a screw) is shown being inserted into part 33.
- Final Assembly:** Part 101 (a bracket) is shown being inserted into part 102 (a bracket). Part 103 (a bracket) is shown being inserted into part 104 (a bracket). Part 102 (a bracket) is shown being inserted into part 101. Part 102 (a bracket) is shown being inserted into part 103 (a bracket). Part 103 (a bracket) is shown being inserted into part 104 (a bracket). Part 104 (a bracket) is shown being inserted into part 101.

Technische Daten / technical specifications / spécification techniques

Luftdruck / air pressure / Pression:
Arbeitsdruck etwa / working pressure about / de travail: 6 bar (90 psi)
max: 8 bar (110 psi)
Luftverbrauch je Eintreibvorgang bei 6 bar: 1,15 l
max. Meßflächen-Impulschalldruckpegel (L_{pAI} max): 93 dB
max. A-Impulsschalleistungspegel (L_{WAI} max): 106 dB
arbeitsplatzbezogener Emissionswert (L_{pAI} max): 99 dB
nach DIN 45635-66-Kl.2
Vibration / vibration: 3,2 m/s²
nach ISO 8662/1 und Ergänzung Dokument Nr. CEN/TC 255 WG 1 N 47.3 (Juli 1994) /
according to ISO 8662/1 and supplementary document No CEN/TC WG 1 N 47.3 (July 1994) /
selon ISO 8662/1 et complété par décret Nr. CEN/TN EWG 1 N 47.3 (Juli 1994)
Dieser Wert ist ein gerätebezogener Kennwert und stellt nicht die auf das Hand-Arm-System
übertragenen Einwirkungen dar.

MOD. A

Gerät · Tool · Aparato · Appareil · Toestel · Verktyget · Työkalu

Modell Model Modelo Modèle Model Modell Malli	Höhe Height Altura Hauteur Hoogte Höjd Korkeus	Länge Length Largo Longeur Lengte Längd Pituus	Breite Width Ancho Largeur Breedte Breidd Leveys	Gewicht Weight Peso Poids Gewicht Vikt Paino
	mm (inch)	mm (inch)	mm (inch)	kg (lbs, ozs)
PN 6040 A	250 (9 7/8)	325 (12 3/4)	70 (2 3/4)	2,3 (5 lbs 1 ozs)
PN 540 A	250 (9 7/8)	325 (12 3/4)	70 (2 3/4)	2,58 (5 lbs 11 ozs)
PN 3030 A	250 (9 7/8)	390 (15 5/16)	70 (2 3/4)	3,25 (6 lbs 15 ozs)
PN 2550 A	250 (9 7/8)	370 (14 9/16)	70 (2 3/4)	2,8 (6 lbs 2 ozs)
PN 750 A	250 (9 7/8)	325 (12 3/4)	70 (2 3/4)	2,58 (5 lbs 11 ozs)
PN 730 A/N	250 (9 7/8)	325 (12 3/4)	70 (2 3/4)	2,58 (5 lbs 11 ozs)
PN 5040 A	250 (9 7/8)	325 (12 3/4)	70 (2 3/4)	2,3 (5 lbs 1 ozs)
PN 7050 A/MM	250 (9 7/8)	385 (15 3/16)	70 (2 3/4)	2,9 (6 lbs 6 ozs)
PN 2575 A/HWL	287 (11 5/16)	370 (14 9/16)	70 (2 3/4)	3,1 (6 lbs 13 ozs)
SKN 64 A/16	250 (9 7/8)	325 (12 3/4)	70 (2 3/4)	2,4 (5 lbs 4 ozs)
SKN 64 A/20	250 (9 7/8)	325 (12 3/4)	70 (2 3/4)	2,4 (5 lbs 4 ozs)
TN 64 A/22	250 (9 7/8)	325 (12 3/4)	70 (2 3/4)	2,4 (5 lbs 4 ozs)
TN 15 A/22	250 (9 7/8)	325 (12 3/4)	70 (2 3/4)	2,4 (5 lbs 4 ozs)
RN 35 A/H	250 (9 7/8)	400 (15 3/4)	70 (2 3/4)	2,2 (4 lbs 13 ozs)

Befestigungs-Elemente · Fastener · Elementos · De Fijacion Agrafes · Clous · Bevestigingselementen · Fästelement · Työkalujen

Modell Model Modelo Modèle Model Modell Malli	Serie Series Serie Série Serie Serie Hakastyyppi	Länge mm (inches) Length mm (inches) Largo Longeur mm (inches) Lengte mm Längd mm (tum) Pituus	Magazin-Kapazität Magazin-Capacity Capacidad-cargador Capacitéchargeur Ladercapaciteit Magasinkapacitet Lipaan kapasiteetti
PN 6040 A	KL 6000	20 — 40 mm (3/4" — 1 5/8")	134
PN 540 A	KL 500	20 — 40 mm (3/4" — 1 5/8")	130
PN 3030 A	FD 3000	15 — 30 mm (5/8" — 1 3/16")	115
PN 2550 A	BK 2500	25 — 50 mm (1" — 2")	160
PN 750 A	KG 700	18 — 50 mm (11/16" — 2")	108
PN 730 A/N	KG 700	20 — 30 mm (3/4" — 1 3/16")	108
PN 5040 A	KL 5000	15 — 40 mm (5/8" — 1 5/8")	134
PN 7050 A/MM	KG 7000	18 — 50 mm (11/16" — 2")	138
PN 2575 A/HWL	BK 2500	44 — 75 mm (1 3/4" — 3")	160
SKN 64 A/16	SKN 16	30 — 64 mm (1 3/16" — 2 1/2")	75
SKN 64 A/20	SKN 20	38 — 64 mm (1 1/2" — 2 1/2")	75
TN 64 A/22	TN 22	32 — 64 mm (1 1/4" — 2 1/2")	72
TN 15 A/22	TN 22	15 mm (5/8")	72
RN 35 A/H	RB 25	22 — 35 mm (7/8" — 1 3/8")	60

haubold-kihlberg GmbH

Befestigungstechnik

Carl-Zeiss-Straße 19

D 30966 Hemmingen

Telefon (05 11) 42 04-0

Telefax (05 11) 42 04-204 Marketing International

Telefax (05 11) 42 04-206 Vertrieb Inland

Telefax (05 11) 42 04-324 Logistik